

KC868-H2 Device User Manual (V0612)

I . Software Downloading	Page 1
II. Remote Controlling Operation	Page1
1. Mobile APP controlling manual	Page 1
2. Computer Program controlling manual (WAN mode).....	Page 5
III. Local Controlling Operation (LAN mode)	Page6
1. Configuration Setting	Page 6
2. Computer Program Setting	Page 7

**※Important: The “Remote Controlling” and the “Local Controlling” are alternative;
You must choose one of them for using.**

I . Software Downloading

1. Use mobile phone to scan the below QR code to download the APP



2. KC868-H2 software (Phone APP QR code, PC Program, Vircom Network Tool) downloading link:

www.kincony.com/download/Disk_KC868-H2.rar

Please download the file to have the software firstly, as below, it is default you already have and know them.

II. Remote Controlling Operation

1. Mobile APP controlling manual


1.1 Power on the device and connect the internet cable

1.2 Register

Downloading and installing the APP,

Register your account (11 digits) and password,

(Pls make a note for your password in case forgotten).





1.3 Adding device

1.3.1: Login in

Choose 【Mine】 - 【My Room】

Add Floor and Room

(Be necessary! Make sure this step)



1.3.2: Floor and Room can be re-named;

Click 【OK】

1.3.3: Choose 【Mine】 - 【Host Manager】

1.3.4: Click 【add】

Scan the QR code on the device

Input a name for the device.

Click 【Add】.



1.3.5: Click 【Mine】 - 【My Device】

- 【Unclassified】

Hold pressing the ICON

Choose one room for the device

Input a name






1.3.6: Click to enter control page

1.3.7: Hold pressing the name of the relay



Input new name

1.3.8: Click 【OK】



1.4 When there is the camera, open it at the home page.

Then it can be showed when entering into the control page.



1.5 Scene linkage operation

1.5.1 Create Scene Mode

Login in APP, Click 【Scene】—【+】or 【Add】—Input Mode name, choose Mode icon,


Time setting Optional(Function of timing), at 【Mode setting】 , input the actions you want to control, click 【Save】;

See below pic1.5-1, pic1.5-2, pic1.5-., pic1.5-4.




Pic1.5-1

Add Scene



Pic1.5-2

Add Scene 2



Pic1.5-3

Time setting (Optional)



Pic1.5-4

Mode setting (Action controlled)

“Mode name” can be named; e.g.: Back Home, Leaving Home, Meeting;

“Mode icon” can be changed;




“Time setting” is for timing (optional), Pic1.5-3, Repeated time: Monday, Tuesday, Wednesday and 7:10 am.

Meaning the scene mode is opened at 7:10 am each Monday, Tuesday and Wednesday.

“Mode setting” is for adding the actions required to control

1. Press ‘Click to add action’, choose KC868H8
2. Press [Enter the ctrl pg], you can set the actions, see Pic4-7
 - a. Open light1
 - b. Press the name, it will save the action
3. Press Execute, you can set Delay time
4. Press ‘Save’

See Pic1.5-5, Pic1.5-6, Pic1.5-7.



Pic1.5-5

Pic1.5-6

Pic1.5-7

2. Computer Program controlling manual (WAN mode)

2.1 Power on the device and connect the internet cable

2.2 Double click “ActiveX Installer.exe” to install it.

(No need to install for future)

2.3 Double click “Net_Relay_Control.exe” to open it.

2.4 Setup the configuration as below steps

2.4.1: Choose 【Mode】 - 【WAN】

2.4.2: Click 【Control Name】 - 【Device Config】



2.4.3: Input Name and Serial Number(S/N)

(Serial Number is the 24 digits on the QR code,
Labeling on the device)

2.4.4: If more devices, Input name and S/N accordingly.

Total four devices can be controlled.

2.4.5: Click 【Save】





2.4.6: Re-start the program, (very important)

2.4.7: Choose Controller

2.4.8: Close the program and open it again.

2.4.9: Choose 【Mode】 - 【WAN】

2.4.10: Control the device




III. Local Controlling Operation (LAN mode)

1. Configuration Setting

1.1 Power on the device and connect the internet cable

1.2 Make sure your computer and the device are belonging to the same local internet



1.3 Open the “Vircom Network Tool”

1.4 Set the configuration of the device.



1.4.1 : Click 【Device】

1.4.2: Click 【Auto Search】


1.4.3: Click 【Edit Device】

1.4.4: Enter into page


【Device Settings】



1.4.3



1.4.5: Choose “TCP Server” for the 【Work Mode】，instead of “UDP”



1.4.6: Keep the others unchanging;

Remember the IP Address and Port



1.4.7: Click 【Modify Setting】

1.4.8: Re-power the device and do the following part 2.

2. Computer Program Setting


2.1 Double click “ActiveX Installer.exe” to install it for first time using.

(No need to install in future)


2.2 Open “Net_Relay_Control.exe”.

2.3 Set the configuration as below steps

2.3.1: Choose 【System】-【Parameter Config】



2.3.2: Input the IP number and Port number. If not remembered, check back from the Vircom tool



2.3.3: Click 【Save】

Re-start the program (**Very important**)

2.3.4: Click 【Local Control】 - 【LAN Connect】

【Connect OK!】 showed at the bottom

2.3.5: Click 【Local Control】 - 【Initialization】

【Initialization completion】 showed at the bottom

2.3.6: Control the device locally

